

PARTS LIST

102" TRAVEL (STD)

ITEM	QTY.	Part No.	DESCRIPTION
------	------	----------	-------------

REAR POST EQUIPMENT



1	1	102617	Cylinder Assembly
2	1	102618	Cylinder Casing Only
3	1	102621	Plunger Assembly
4	1	102688	Pitform and Pipe Cover
5	1	102625	Superstructure
6	2	102706	Rear Jack
7	1	11199	Pipe 4" O.D. x 77" Long
8	4	10212	Soc. Hd. Cap Scr. — 7/8" - 9 NC x 2-3 4" LG

FRONT POST EQUIPMENT

9	1	102606	Cylinder Assembly
10	1	102607	Cylinder Casing Only
11	1	102615	Plunger Assembly
12	1	102711	Front Frame
13	1	102651	Superstructure
14	2	102713	Frame Cover (Hinged)
15	1	102712	Frame Cover (Detachable)
16	2	102707	Axle Assembly
17	2	102708	Bowl Jack Assembly
18	2	102710	Angle Jack Assembly
19	1	11286	Chain (27'-0")
20	1	11151	Hose
21	1	102936	Handle for Ratchet
22	4	10209	Soc. Hd. Cap Scr. — 7/8" - 9 NC x 2" LG

CONTROLS

23	1	100785	Oil Tank (Air/Oil)
24	1	101600	Oil Gauge Stick
25	1	102729	Control Box (Air/Oil)
26	1	11943	Air Valve (Air/Oil)
27	1	102933	Handle for Air Valve
28	1	10932	Air Exhaust Muffler
29	2	11800	Oil Valve (Air)
33	1	103987	Control Box (Electric/Oil)
34	2	103988	Oil Valve (Electric/Oil) (Spring Loaded)
35	2	103951	Handle for Oil Valve



For detail of Cylinders see page 19

